

Tester and magnetic field meter


OP-FSM

The OP-FSM is an ideal solution for measuring, adjusting and commissioning a magnetic induction loop system in accordance with the IEC 60118-4 specification.

It allows precise measurement of the field strength in an area covered by a magnetic induction loop.

The LOW adjustment range is designed to measure crosstalk between loop systems and interference from network equipment such as lights, dimmers, or hardware.

It is equipped with a filter to measure the audio signal of the loop that the human ear hears and also broadcasts the test signals.



All measurements are taken at OdB defined as 100mAM-1 RMS using a next-line PPM response rectifier.

Scale calibration	
Operating mode-20dB	-20dB = 0,043A/m
Operating mode 0dB	0dB= 0,4A/m
Type of measurement	True RMS 125ms
Frequency response	
Filter	A/Flat
30Hz500Hz	-3dB4dB
500Hz2500Hz	+/- 0,25dB
2500Hz10KHz	+/-3dB
Outputs	
Display	Color-coded LED dot display
Headphones	3,5mm cinch
Power supply	
Batteries	2xAA
Incator lights	LED
Service life	100h
Dimensions	
Dimensions (L x H x P)	83 x 126 x 35 mm
Weight	Approx. 300g

Tel: (+33) 09.81.24.00.06 Mail: contact@opus-technologies.fr www.opus

OPUS Technologies

Headset

OP-778



The OP-778 is an excellent value for money.


Adjustable and equipped with shape memory earmuffs, it allows a better listening comfort. It is light and foldable for more mobility and space saving storage.

Line length	1m20
Sensibility	120±3dB
Resistance	16Ω
Frequency response	20 - 20000 Hz
Connectors	3,5mm Jack
Certifications	CE, ROHS





Costumer Informations									Installer Informations								
Client :									Installer:								
Room:									Company:								
Adresse :									Device :								
									Serial Number :								
								Te	Tested by :								
	DOONA	CVETCU															
1		SKETCH room and the	coverage	area indi	cating m	easure	ment poi	nts and bo	ackgroui	nd noise	1						
2	Amplifier	off and OP-FSN The existence	M in "-20a	IB" positi	on. Note	the tol	erable or	polluted i	interfere				the IEC 60	118-4 stan	dard		
Accep		kgroud noise						oud nois							areas < -	22 dB □	
	MAKE	MEASURES	S														
Draw on the sketch 6 to 8 points corresponding to measurements made IEC 60118-4 standard states that the listening height is 1.2m for a sittir																	
	uring po		Α	В	(С	D	E	F	: 4	A1	B1	C1	D1	E1	F1	
Magn	atic field	I (4B))															
Refore																	
Before Frequ	settings, w	ith pink noise															
Frequ respo	settings, w uency onse	100Hz															
Frequ	settings, w uency onse	ith pink noise															
Frequ respo	settings, w uency onse	100Hz															
respo After so	settings, water teach te	100Hz 1KHz 5KHz															
respo After so	settings, w uency onse ettings netic field ettings, wit	100Hz 1KHz 5KHz 1 (dB) h audio source															
respo After so	settings, with settings, with settings.	100Hz 1KHz 5KHz	nade on th	ne magne	etic induc	ction lo	op amplij	ier		Lo	op2	Loop1	Input1	Input2	lnout3	MLC	
Frequence After so	settings, we provide the settings with the setting with the set	100Hz 1KHz 5KHz 1 (dB) h audio source adjustments n	nade on th	ne magne	etic induc	etion lo	op amplij	ier		Lo	op2	Loop1	Input1	Input2	Input3	MLC	
Frequence After so	settings, water the settings with the settings with the settings.	100Hz 1KHz 5KHz 1 (dB) h audio source	leted, the	staff of t	the equip	ped sit	e must be	e informed		epared to	o guide	the hearir	ng impaire	d in the use	of the syst	em.	
Frequence After so	settings, with the settings with the settings with the settings. With the settings with the settings with the settings. With the settings with the settings with the settings with the settings with the settings.	100Hz 1KHz 5KHz 1 (dB) h audio source IGS MADE adjustments n CHECKS tests are comp	leted, the	staff of t	the equip	ped sit	e must be	e informed		epared to	o guide on cann	the hearir	ng impaired ared in acc	d in the use	of the syst	em.	
Frequences of After solution After s	settings, with the settings with the settings with the settings. With the settings with the settings with the settings. With the settings with the settings with the settings with the settings with the settings.	100Hz 1KHz 5KHz 1 (dB) h audio source IGS MADE adjustments n CHECKS tests are compoil Heaing Aidr"	leted, the	staff of t	the equip	ped sit	e must be	e informed		epared to	o guide on cann	the hearir	ng impaired ared in acc	d in the use	of the syst	em.	
Frequences of After solution After s	settings, water the settings of the settings o	100Hz 1KHz 5KHz 1 (dB) h audio source IGS MADE adjustments n CHECKS tests are compoil Heaing Aidr"	leted, the	staff of t	the equip ued and v	ped sit	e must bi	e informed	ise, the i	epared to nstallatio Visi	o guide on cann ble sti	the hearir	ng impaired ared in acc	d in the use	of the syst	em.	
Magra After so	settings, with the settings of	100Hz 1KHz 5KHz 1 (dB) h audio source IGS MADE adjustments n CHECKS tests are compoil Heaing Aidr" nember:	leted, the	staff of t	the equip ued and v	ped sit	e must bi	e informed	18-4	epared to nstallation Visi	o guide on cann ble sti	the hearin ot be decl ckers ?	ng impaired ared in acc	d in the use	of the syst	em.	
Frequences of After solution After s	settings, with the settings wi	100Hz 1KHz 5KHz 1 (dB) h audio source IGS MADE adjustments n CHECKS tests are compoil Heaing Aidr" nember:	leted, the	staff of t	the equip ued and v	ped sit	e must bi	e informed	18-4	epared to nstallation Visi	o guide on cann ble sti	the hearin ot be decl ckers ?	ng impaired ared in acc	d in the use	of the syst	em.	





www.opus-technologies.fr



contact@opus-technologies.fr



+33(0)9 81 24 00 06

Procedure of AFILS verification to IEC 60118-4

AFILS system are the most universal and effective way to allow public venues accessible to hearing impaired people. However, to be effective, these systems must be carefully calibrated to verify that the installation has been done in compliance with IEC 60118-4. Opus Technologies strongly recommends issuing a certificate of conformity to this standard, according to the attached model, signed by the installer or supplier.

The IEC 60118-4 standard of March 2014

This standard defines 4 very specific parameters:

- The peak magnetic field must reach 400mA / m (integration time 0.125ms)
- Frequency responses should not vary by more than 3dB between 100Hz and 5000Hz
- The signal-to-noise ratio must be 47 dB (A-weighted)
- The magnetic field must be uniform throughout the listening area

To allow a good listening it is necessary to check all these conditions:

The respect of the intensity of the magnetic field ensures that the loudness is sufficient, the frequency responses make it possible to verify that the whole sound spectrum is perceived in the same way and the signal-to-noise ratio measures the impact of parasitic magnetic disturbances. on intelligibility.

Despite the installation of adequate equipment many factors can disturb these parameters: the presence of metal structures causes the magnetic field to drop, transformers or current at 50 Hz nearby cause magnetic noise. The size and shape of the room can make it difficult to respect the recommended values at all points of the room.

The testing procedure

We recommend the following procedure:

- Determine and draw on your room plan, the points where the measurements will be made (center, ends, point near metallic structures or noise sources)
- Installer's measurements of the three parameters set by the standard, before and after the adjustment of the installed equipment.
- Inform and train staff so they will be able to guide hearing impaired people for using it in the best conditions
- Delivery of this document signed by the installer or supplier to the manager of the room.

Recommendation

Venues managers must ensure, during any magnetic induction loop installation, that the installer deliver this certificate of compliance. Even if the manager does not have the competence to judge the result of the measurements, the installation report should be accessible at any time for a possible control by a team of auditors.